



使用者手冊

索引目錄

一、安全及注意事項.....	3
二、使用前準備工作.....	5
1. 電池不可拆卸.....	5
2. 電池的充電.....	5
3. SIM卡的插入與取出.....	5
4. 存儲卡的插入和取出.....	5
5. 開關手機.....	5
6. 安全密碼.....	6
三、智能機使用答疑.....	6
四、主要功能指南.....	8
1. 桌面.....	8
2. 添加桌面小部件.....	8
3. 聯繫人.....	8
4. 打電話.....	9
5. 發信息.....	9
6. 文本輸入.....	9
7. 電子郵件.....	9
8. 拍照或視頻.....	9
9. 圖庫.....	9
10. 通知面板.....	9
11. 音樂.....	9
12. 切換多任務.....	10
13. 瀏覽器.....	10
14. 設置.....	10
五、常見故障診斷.....	10
六、重要聲明.....	11
1. 關於手機.....	11
2. 免責條款.....	12
3. 限制賠償.....	12
七、更多信息.....	12

一、安全及注意事項

使用手機時，請遵循以下注意事項：

- 使用之前，請注意詳細閱讀使用說明書。
- 在飛機上，請始終關閉手機。如果您的手機的鬧鐘、日程等在關機狀態下具備自動開機功能，請在登機前檢查並取消設置。
- 使用手機時，應遠離熱源、高電壓環境，例如：電器或電熱烹飪設備。在正常溫度下使用，溫度高於40°C或低於-10°C的環境下會損傷您的手機。
- 注意防火。在加油站、燃料倉庫等易燃品附近請關機。
- 開車時嚴禁手持手機。請不要將手機放在氣囊上方或氣囊展開後能夠觸及的區域內，以免氣囊膨脹時，手機受到很強的外力，可能對您造成嚴重傷害。
- 只能使用本公司認可的標準電池、充電器和附件。對因使用第三方的附件造成的任何後果，本公司不承擔任何責任。
- 嚴禁擅自拆卸手機。
- 手機靠近其他電子裝備時會對其造成干擾。請遠離電子裝備，例如：電視機、收音機、個人電腦、心臟起搏器和助聽器等設備。嚴禁將手機放於信用卡或磁場附近。在醫院或其他特殊場所，請遵循特殊場所相關規定使用您的手機。
- 嚴禁使手機受到機械振動或晃動。嚴禁用利器敲擊螢幕。
- 如果使用手機套或塑膠手機套可能會損壞手機外殼塗層。
- 嚴禁使用溶解物，如：苯、稀釋劑或酒精，擦拭手機外殼，嚴禁讓有腐蝕性的化學物品、清潔劑接觸手機。只能使用乾淨的軟布輕輕的擦拭您的手機。
- 嚴禁將手機暴露在陽光下，或過多煙霧與灰塵的地方。
- 保持手機乾燥，嚴禁在濕度高的環境中使用，如浴室。該設備不防水，嚴禁使其淋雨或受潮。
- 如果您的手機是外置天線，如無必要，嚴禁觸摸天線，僅可使用原裝的天線，如果使用未經許可的天線有可能會造成手機的損壞。當您要把充電器介面從您的手機上拔出時，抓緊介面往外拉，嚴禁拉電源線。
- 請不要只依靠手機作為緊急時刻的通信工具，如醫療救護。
- 請將手機放在兒童接觸不到的安全地方，以防發生危險。

使用電池時，請遵循以下注意事項：

- 使用之前，請注意詳細閱讀使用說明和電池表面標識。
- 請在涼爽、通風的室內給電池充電。否則充電時環境溫度過高，會引起電池的發熱、冒煙、燃燒或變形，甚至爆炸。
- 電池內部有特殊的保護電路和裝置，嚴禁擅自拆開電池，否則會造成短路或者電解液滲漏。若電解液進入眼睛會有失明的危險。這時請立即用清水沖洗眼睛（千萬不要揉眼睛），並立即到醫院就診。
- 嚴禁擠壓電池，嚴禁機械振動或晃動電池，嚴禁使電池短路，因為這樣會損壞電池或與之連接的元件。短路可由一些金屬物品，例如硬幣、筆和回形夾

等直接把電池的正極和負極連接起來，因此嚴禁把電池跟金屬物品放在一起。

- 請保持金屬觸點和電池清潔。
- 嚴禁使用已損壞或已用盡的電池。
- 請在電池無法滿足性能要求時進行更換。電池可以充數百次電，直到需要更換。電池是消耗品，雖然它可以上百次的充放電，但它的電量會慢慢的減少。當您發現使用時間（通話時間和待機時間）減少時，即應該更換一塊新電池。
- 嚴禁將電池暴露在陽光下，或過多煙霧與灰塵的地方。嚴禁在濕度高的環境中使用，如浴室。該設備不防水，嚴禁使其淋雨或受潮。
- 嚴禁將電池放置在過熱或過冷的地方，溫度高於40°C或低於-10°C的環境下會影響電池性能。
- 嚴禁將電池擲入火中，以免發生爆炸。
- 嚴禁將電池放在水中，以免引起內部短路，造成電池發熱、冒煙、變形、損壞、甚至爆炸。
- 請按規定處理電池（如回收），不可將電池作為生活垃圾處理，以免引起爆炸和污染。
- 本電池只能使用專用的充電器充電，並且連續充電的時間嚴禁超過12個小時。
- 請將電池放在兒童接觸不到的安全地方，以防發生危險。

使用充電器時，請遵循以下注意事項：

- 使用之前，請注意詳細閱讀使用說明書和充電器表面標識。
 - 請不要拆卸或改裝充電器，嚴禁在電源線損壞的情況下使用充電器，否則會導致觸電、起火和充電器損壞。
 - 嚴禁用濕手接觸充電器。如果充電器接觸到水或其他液體，要立刻切斷電源。
 - 嚴禁短路充電器，嚴禁機械振動或晃動充電器，嚴禁陽光直射，嚴禁在浴室等高濕度的地方使用充電器。該設備不防水，嚴禁使其淋雨或受潮。
 - 請不要在電視機、收音機等電器附近使用充電器。
 - 拔插頭時要抓住充電器，拉電源線會損壞電線。
- 充電時一定要將手機和充電器置於環境溫度為-10°C~+40°C的通風處，並且一定要使用廠商所提供的充電器。使用未經認可的充電器可能會引起危險，同時也違反廠商規定的保修條款。
- 請將充電器放在兒童接觸不到的安全地方，以防發生危險。
 - 使用耳機時(您可能需要額外購買耳機)，請遵循以下注意事項。
 - 使用耳機時請注意控制適當的音量，以免損傷聽覺。
 - 請勿用力拉扯耳機線，以免出現斷裂現象。
 - 在高溫高濕的場所長時間使用耳機，容易造成耳機損壞或使用壽命降低。

- 駕駛汽車、騎自行車或馬路上行走時，請勿使用耳機，否則容易導致交通意外。
- 請將耳機放在兒童接觸不到的安全地方，以防發生危險。

注意：本產品不配備電源適配器上市銷售，若消費者自行配備電源適配器時，應購買滿足相應安全標準要求的電源適配器或者是獲得CCC認證的電源適配器，電源適配器應符合輸出規格為：5VDC 2A。消費者自行配備的電源適配器如不能符合要求時可能存在起火、漏電、爆炸的安全風險”。

二、使用前準備工作

1. 電池不可拆卸

電池是內置不可拆卸的
如要更換電池請專業維修人員更換。

2. 電池的充電

將充電器插上電源，然後將充電器的介面插入手機充電器插口，如圖示：

初始狀態電池充了約50%的電量，拆開後即可使用。前三次充電請徹底用完電後再充滿使用，這樣電池易達到最佳使用狀態。

注：請小心操作，不要強行拔出充電介面，這樣可能會損壞手機或充電器。

在充電時請勿拆除電池或SIM卡。

3. SIM卡的插入與取出

SIM卡的金屬接觸面很容易刮損。在裝配之前，必須小心將其取出。

關閉手機，移去其他外部電源和電池。將SIM卡插入SIM卡座，插入時確保SIM卡的方向正確，

當您需要取出SIM卡時，請先關機，移去其他外部電源和電池，再取卡。

4. 存儲卡的插入和取出

將存儲卡插入SIM卡座上面的存儲卡槽，插入時確保SIM卡和存儲卡方向正確

5. 開關手機

確保電池已經安裝好。開機時，按住[電源鍵]，直至顯示幕出現開機的畫面。某些SIM卡會有PIN碼保護。如果有輸入PIN碼提示，輸入您的PIN碼。PIN碼

的初始密碼一般為1234。開機後，如果插入的SIM卡有效，手機將自動搜索可用網路。關機時按住[電源鍵]，直至出現關機的選項。

6. 安全密碼

您可以使用該節描述的訪問密碼來避免他人擅自使用您的SIM卡。

PIN碼

用於防止用戶的SIM卡被非法使用。若您的手機已啟動PIN碼保護功能，開機後，螢幕會顯示輸入PIN碼的提示。如果連續三次輸入錯誤的PIN碼，SIM卡將自動上鎖。您必須輸入PUK碼才能解鎖。PIN碼與SIM卡有關，而與手機無關，PIN碼由網路運營商提供。

注：PIN碼的初始密碼一般為1234。

PUK碼

PUK碼是個人解鎖碼，被用作解開因為連續三次錯誤輸入PIN碼而被鎖上的SIM卡。如果累計10次輸入錯誤的PUK碼，SIM卡將失效。PUK碼由網路運營商提供。

三、智能機使用答疑

什麼是智能手機？

是指“像個人電腦一樣，具有獨立的操作系統，可以由用戶自行安裝軟體、遊戲等第三方服務商提供的程式，通過此類程式來不斷對手機的功能進行擴展，並可以通過移動通訊網絡來實現無線網路接入的這樣一類手機的總稱”。智能機有CPU/RAM/ROM，相當於電腦的CPU/記憶體/硬碟。

智能手機和非智能機的區別？

1. 智能手機的CPU處理器更強，記憶體也比較大，可以處理很多應用功能；而非智能手機智能處理一些常用的軟體。

2. 智能手機在操作上較人性化、便捷使用，如菜單快捷可隨意拖至桌面，短信檔內容等可複製粘貼；而非智能機實現不了。

3. 智能手機可下載豐富的第三方軟體應用；非智能機不可以。

如何安裝第三方應用？

該智能手機在出廠時就已經預置了相關的應用程式，能夠滿足普通用戶的基本需求。用戶也可以從電子市場（如：安智市場）、第三方管理軟體下載安裝其他第三方應用，或者通過USB數據線拷貝第三方應用程式到手機上並安裝。請注意，只有預置的應用是經過測試並保證使用效果的，其他用戶自行下載

的應用需要確認該應用經過Google的授權並獲得數字簽名方能保證使用效果。如果用戶需要安裝非Google授權的應用，需要在 主菜單->系統設置->安全->中勾選“未知來源”這一選項。安裝非認證的應用存在風險，一切由於用戶自行安裝非授權應用引起的軟硬體問題聯想不承擔維修責任。還請用戶儘量下載官方認證的應用。

第三方應用的下載和安裝需要收費嗎？

目前Android應用中超過半數都是免費的，安裝和下載這部分應用都不需要收費。但是，下載帶來的數據流量是需要收費的，收費標準請諮詢當地運營商。建議您在WLAN環境下下載應用程式，並且在沒有數據流量包月套餐或套餐流量即將耗盡情況下，關閉 主菜單->系統設置->SIM卡管理中的“數據連接”(下拉狀態欄的開關頁中，也有數據連接開關)，由於用戶個人沒有關閉應用帶來的高額流量費用，本公司不承擔相關責任。

發現系統速度越來越慢該如何處理？

- 1.智能手機和電腦一樣，可能在長時間運行多個程式後會發現系統逐漸變“卡”，此時重啟手機就可解決該問題；
- 2.如果重啟還解決不了問題的話，回憶一下最近您是否下載安裝過一些新的第三方應用程式，進入 系統設置->應用程式，嘗試卸載最近安裝的程式後再重啟手機；
- 3.如果以上兩種方法都解決不了您的問題的話，進入 系統設置->備份和重置->恢復出廠設置，可將手機恢復出廠設置，請注意！做此操作前注意使用手機自帶的備份與恢復工具備份您的重要數據，或可以使用第三方工具，如“91手機助手”等。

使用中死機了怎麼辦？

既然是和臺式機WindowsXP一個性質的開放式操作系統，當受到非法程式干擾而死機，也就司空見慣。所以最好不要肆意安裝各種應用軟體。另外，軟體裝多了、文檔存多了，手機的數據讀寫速度也會變慢，這和“死機”的道理相同。建議（適當關機）

為什麼我們玩一會遊戲電池就很發燙呢？

玩遊戲軟體時，CPU和運行記憶體RAM都是高速運轉，肯定很耗費電，產生熱量。你用iphone4玩一會遊戲，手機溫度也很快就升高了。即使用電腦玩遊戲，電腦的溫度也比不玩遊戲時溫度高；

電池不耐用如何處理？

智能手機多為大屏手機，且支持的功能眾多，如果您長時間上網、看視

頻、玩遊戲，那麼電池的續航時間也會相應地減少。那麼怎樣才能盡可能延長電池的續航時間及其使用壽命呢？在您不需要無線連接的時候，關閉WLAN、藍牙、GPS、Exchange帳戶同步，在燈光昏暗或者夜晚時，建議您調低螢幕亮度，不僅能延長手機的使用時間，更能保護您的視力。而這些可能都可以通過貼心的省電管理來實現。

為什麼軟體安裝不了，被強制性關閉？

軟體安裝不了，一是軟體版本是否支持手機相應的版本號；二是軟體是否安裝成功，包括數據包；三是軟體之間可能會有衝突。

如何調出後臺運行的程式？

長按Home鍵，可調出最近正在使用的程式。

手機通話後為什麼會滅屏？(如果機器帶光距離感測器)*

在通話過程中黑屏有兩個好處，第一是可以省電，第二是手機螢幕比大也是觸屏手機，以免誤觸摸其他按鍵，引起誤操作。滅屏有兩種原因，第一個原因是距離感應器，智能手機特意增加這個功能的，當你接聽電話的時候靠近耳朵的時候屏滅，這樣也是避免臉或者是什麼碰觸其他按鍵，引起誤操作，當你拿離開耳朵屏就自然點亮，這個時候可以進行任何的操作；第二個原因是螢幕自然滅了，這個時候你可以按下power鍵點亮螢幕。

四、主要功能指南

1.桌面

進入桌面，您可以點擊圖示打開對應的程式，也可以長按後拖動圖示來排序或刪除。刪除圖示時長按該圖示至螢幕出現“x刪除”，把圖示拖拽至此處鬆開即可（注：刪除程式快捷鍵但不會刪除程式）。

2.添加桌面小部件

要添加桌面小部件您可以在窗口小部件介面選擇你要的小工具，長按並把小工具拖拽至桌面空白處即可。刪除時同上。

3.聯繫人

初次使用，請選擇導入聯繫人的方式，手機支持多種方式添加聯繫人。您可以導入SIM卡、SDCard聯繫人或者設置同步帳號，也可以直接新建聯繫人。

4.打電話

當網路供應商的標誌在顯示幕上出現時，您就可以撥打或接聽電話了。顯示幕上方的資訊條顯示網路信號強度。通話品質受障礙物的影響比較大，所以在小範圍內的移動可以有效提高通話品質。

您可以通過鍵盤直接撥打電話，也可以用來搜索聯繫人。支持搜索聯繫人姓名拼音的首字母，部分拼音和電話號碼，搜索結果按照匹配和聯繫頻率優化排序。

5.發信息

編輯資訊，您可以一次添加一個或多個收信人，短信內容支持發送文字或插入圖片、音頻、視頻等。

6.文本輸入

此款手機已為您提供自帶輸入法。您也可自行下載其他輸入法進行安裝使用。選擇輸入法後，您可根據輸入法介面的圖示點擊切換輸入模式。

7.電子郵件

首次使用需添加設置郵箱帳號，設置好後即可用手機來發送和接受郵件，有新郵件時，會收到提醒。

8.拍照或視頻

打開相機程式拍攝、照相，支持快速調節焦距，可設置特效等拍攝模式。拍攝視頻可在菜單中切換到攝像模式。

9.圖庫

進入圖庫程式，您可以通過雙擊或兩指捏合來縮放單張圖片，可以左右滑動來切換上一張或下一張圖片。單擊圖片可以顯示或隱藏功能菜單，可選擇資訊、藍牙、電子郵件等方式分享圖片；點擊菜單鍵可獲得更多操作。

10.通知面板

您可以在收到新的通知時，開啟通知面板以查看資訊、日曆、活動通知。通知面板可快速開啟WIFI、藍牙、GPS、數據連接等設定。開啟通知面板，請按住狀態欄，然後向下滑動。如果出現多個通知，只要上下滑動畫面就可以查看全部通知。

11.音樂

音樂程式支持播放本地音樂，支持按歌曲名、歌手、專輯、播放列表不同模式播放歌曲。

12. 切換多任務

手機支持同時運行多個任務，在多個任務中切換您只需要在解鎖狀態下長按“Home鍵”，選擇您要切換的程式點擊即可進入，也可左右滑動來關閉不需要的任務。

13. 瀏覽器

瀏覽器支持雙擊或兩指捏合來縮放網頁，通過網址導航可快速訪問網址。

14. 設置

在待機介面按筆觸螢幕進入主菜單，然後選擇設置，將進入設置介面。您可以在此菜單選項中按照您的使用習慣設置您的手機。

五、常見故障診斷

- 在使用電話過程中出現任何問題，請參照下列條款加以解決。如果問題仍然存在，請立即與指定經銷商或維修商聯繫。

- 螢幕出現輸入PIN：
輸入SIM卡所帶的有效PIN密碼。如果您不知道密碼，請立即與網路服務供應商聯絡。

- 螢幕出現輸入PUK碼：
三次輸入錯誤的PIN碼後，您的SIM卡將會被鎖住，要解鎖，您必須輸入PUK碼，請立即與網路服務供應商聯絡。

- 螢幕出現插入SIM卡資訊：
確認SIM卡安裝正確。檢查SIM卡是否正常工作，其可能有缺陷或出現故障。如果是這樣，請交付網路服務供應商解決。

- 顯示不在服務區，網路故障：
檢查信號強度指示器。如果無網路信號，您可能處於地下室或建築物中的網路盲區。移至其他地區接收信號。還有另外一種情況，您可能處於網路未覆蓋區，可以要求您的網路服務供應商提供網路服務範圍。

- 聲音品質差，回音或有雜訊使通話困難：
掛斷電話，再次撥號，網路服務供應商可能為您轉接一條通話品質較好的

線路。

- 待機時間變短：

所在地信號較弱，手機長時間尋找信號所致。在您不想接聽電話時，請臨時對機；或者電池使用時間過長，電池使用壽命將至，需更換新電池

- 手機不能開機：

檢查電池電量或充電。可以在充電期間，打開手機檢驗一下。手機如果長時間靜置後容易使電池過度放電，此時無法開機，充電時開始較長時間內也無回應，需要等電量恢復後才能開機。

- 不能發送短資訊：

您要檢查您的服務中心號選項，您可能沒有開通SMS服務，或者短資訊發送對象無效，或您所在地區的網路服務供應商不支持該項服務。

- 不能充電：

有三種可能：一是手機充電器工作不良，您可以就近與指定維修商或經銷商聯絡；二是環境溫度不適宜，可以更換充電環境；三是接觸不良，可以檢查充電器插頭。

- 電話本不能添加數據：

電話本存儲已滿。可刪除部分原有無用條目。

- 不能選擇某些功能：

沒有開通此項服務或者所在地的網路服務供應商不支持該服務。請與指定維修商、經銷商或網路服務供應商聯絡。

六、重要聲明

1.關於手機

本公司保留不作預先通知的情況下對產品進行改進的權利，對公司產品的性能說明保留最終解釋權。本公司致力改善產品的品質，不斷推出更新版本，故說明書所載與產品的功能、規格或涉及略有不同，請以您的手機為準，此類更改恕未能另行通知，敬請諒解。

2.免責條款

對於預裝或捆綁於本產品中的任何遊戲、應用程式包括相應檔（以下簡稱軟體），或通過本產品取得的視聽資料、內容、服務以及相關檔資料，包括但不限於任何圖像、照片、動畫、錄影、錄音、音樂、文字，（以下簡稱服務）皆由相應軟體/服務提供商（以下簡稱提供商）負責其合法、真實和準確，並由提供商保證不違反國家法律、法規、公共道德及侵犯任何第三方之合法權益。提供商保證所提供軟體和服務的品質以及用戶資料等資訊安全和網路安全。對於本產品用戶在安裝/使用軟體或者使用服務而發生的一切問題，或其他因使用前述軟體或服務而造成的一切問題，包括因前述問題所產生之任何直接、間接、附帶或因此而導致之衍生性損失，概由相應提供商承擔責任，皆與本公司無涉。部分軟體和服務需要網路支持，並可能需要支付相應費用。本公司對產品及使用手冊擁有最終解釋權。

3.限制賠償

依據現行法律允許的最大範圍，任何情況下，本公司與其供應商不對使用者或第三方賠償任何直接、間接、特殊、偶然的、無法避免的損害或損失，包括但不限於對在合約履行與侵權行為中可能發生的收入損失、信譽損失、商業機會損失、資料損失、利益損失、履行或不履行義務均不負責。

七、更多信息

關於兩款預裝App：D-Chat App和D-Zone App的使用幫助，可以掃描下方二維碼獲取完整的使用手冊。





User Manual

Table of Contents

I. Safety and Precautions.....	3
II. Preparations Before Use.....	6
Non-Removable Battery.....	6
Battery Charging.....	6
SIM Card Insertion and Removal.....	6
Memory Card Insertion and Removal.....	6
Powering the Phone On/Off.....	7
Security Passwords.....	7
III. Smart Phone Usage FAQs.....	7
IV. Main Function Guide.....	9
1. Home Screen.....	9
2. Adding Home Screen Widgets.....	9
3. Contacts.....	10
4. Making Calls.....	10
5. Sending Messages.....	10
6. Text Input.....	10
7. Email.....	10
8. Taking Photos/Videos.....	10
9. Gallery.....	10
10. Notification Panel.....	10
11. Music.....	10
12. Multi-task Switching.....	10
13. Browser.....	11
14. Settings.....	11
V. Troubleshooting Common Faults.....	11
VI. Important Statements.....	11
1. About the Phone.....	11
2. Disclaimer.....	12
3. Limitation of Liability.....	12
VII. More Information.....	12

I. Safety and Precautions

Please observe the following precautions when using the phone.

- Read the user manual carefully before use.
- On an aircraft, always turn off the phone. If the phone's alarm or calendar can auto-power on when off, check and cancel these settings before boarding.
- Use the phone away from heat sources and high-voltage environments, such as electrical appliances or electric heating equipment. Operate at normal temperatures; environments above 40°C or below -10°C may damage the phone.
- Fire safety: Power off near flammable materials such as gas stations and fuel depots.
- Do not hold the phone while driving. Do not place it above the airbag or in areas reachable when the airbag deploys; strong impact during inflation may cause serious injury.
- Use only standard batteries, chargers and accessories approved by the manufacturer. The manufacturer is not liable for consequences caused by third-party accessories.
- Do not disassemble the phone without authorization.
- The phone may interfere with other electronic devices. Keep it away from TVs, radios, PCs, pacemakers and hearing aids. Do not place it near credit cards or magnetic fields. Comply with regulations in hospitals and other special locations.
- Do not subject the phone to mechanical vibration or shock. Do not tap the screen with sharp objects.
- Phone cases or plastic covers may damage the housing finish.
- Do not clean the housing with benzene, thinner, alcohol or corrosive cleaners. Wipe gently only with a clean soft cloth.
- Do not expose the phone to direct sunlight, smoke or dust.
- Keep the phone dry. Do not use it in humid environments such as bathrooms. The device is not waterproof; do not expose it to rain or

moisture.

- If the phone has an external antenna, do not touch it unless necessary. Use only the original antenna; unauthorized antennas may cause damage. When disconnecting the charger, pull the connector, not the cable.
- Do not rely solely on the phone for emergency communications, such as medical emergencies.
- Keep the phone out of the reach of children.

Battery Precautions

- Read the instructions and battery markings carefully before use.
- Charge in a cool, well-ventilated room. Excessively high temperatures during charging may cause overheating, smoking, fire, deformation or explosion.
- The battery contains protection circuits. Do not disassemble it; this may cause short circuits or electrolyte leakage. If electrolyte enters the eyes, rinse immediately with clean water (do not rub) and seek medical attention.
- Do not squeeze, vibrate, shake or short-circuit the battery. Short circuits can be caused by metal objects (coins, pens, paperclips) touching the terminals. Do not store the battery with metal items.
- Keep metal contacts and the battery clean.
- Do not use damaged or exhausted batteries.
- Replace the battery when performance declines. Batteries can be charged hundreds of times. Replace when talk or standby time shortens.
- Do not expose the battery to direct sunlight, smoke or dust. Do not use in humid environments. It is not waterproof.
- Do not place the battery in temperatures above 40°C or below -10°C.

- Do not throw the battery into fire.
- Do not immerse the battery in water.
- Dispose of batteries properly (e.g., recycling). Do not discard as household waste.
- Charge only with the dedicated charger; continuous charging must not exceed 12 hours.
- Keep the battery away from children.

Charger Precautions

- Read the manual and charger markings carefully before use.
- Do not disassemble or modify the charger. Do not use if the power cord is damaged.
- Do not touch the charger with wet hands. Unplug immediately if it contacts water or liquid.
- Do not short-circuit, vibrate, shake or expose the charger to direct sunlight. Do not use in humid environments. It is not waterproof.
- Do not use near TVs, radios or other appliances.
- Unplug by gripping the charger, not the cable.
- Charge at -10°C to $+40^{\circ}\text{C}$ in a ventilated area. Use only the manufacturer's charger. Unapproved chargers are dangerous and void the warranty.
- Keep the charger away from children.

Headset Precautions (may be purchased separately)

- Use appropriate volume to avoid hearing damage.
- Do not pull the cord forcefully.
- Prolonged use in high-temperature/humid environments may reduce lifespan.
- Do not use while driving, cycling or walking on roads.
- Keep the headset away from children.

Note: This product is sold without a power adapter. If purchased separately, use an adapter meeting safety standards or CCC-certified, with output: 5VDC 2A. Non-compliant adapters may cause fire, electric shock or explosion.

II. Preparations Before Use

Non-Removable Battery

The battery is built-in and non-removable. For replacement, contact professional service personnel.

Battery Charging

1. Plug the charger into a power outlet, then insert the connector into the phone's charging port.
2. The battery is pre-charged to approximately 50%. For optimal performance, fully discharge and recharge three times initially.

Notes:

- Do not force the connector to avoid damage.
- Do not remove the battery or SIM card while charging.

SIM Card Insertion and Removal

- Metal contacts are easily scratched. Handle carefully.
- Insert: Power off, disconnect power. Insert the SIM card into the tray with correct orientation.
- Remove: Power off, disconnect power, then remove the SIM card.

Memory Card Insertion and Removal

Insert the memory card into the slot above the SIM tray with correct orientation.

Powering the Phone On/Off

- **On:** Press and hold the Power key until the startup screen appears. Enter PIN if required (default: 1234). The phone searches for networks automatically.
- **Off:** Press and hold the Power key, then select power off.

Security Passwords

PIN Code

- Prevents unauthorized SIM use. Enter on startup if enabled.
- Three incorrect attempts lock the SIM. Unlock with PUK code.
- PIN is SIM-specific, provided by the operator. Default: 1234.

PUK Code

- Unlocks SIM after three incorrect PIN entries.
- Ten incorrect PUK attempts invalidate the SIM.
- PUK is provided by the operator.

III. Smart Phone Usage FAQs

What is a smart phone?

A mobile device with an independent operating system, allowing installation of third-party software, function expansion and installation of third-party software, function expansion and wireless network access. It includes CPU/RAM/ROM similar to a PC.

Smart Vs. Feature Phone

1. More powerful CPU and memory for multi-tasking.
2. More user-friendly operations (drag icons, copy/paste).
3. Supports third-party app installation.

Installing Third-Party Apps

- Pre-installed apps meet basic needs. Download from app markets, third-party tools or via USB.
- Only pre-installed apps are tested. Downloaded apps should have Google authorization and signatures.
- To install uncertified apps: Settings → Security → Unknown Sources.
- Manufacturer is not liable for uncertified apps.

Are Downloads Free?

- Most Android apps are free. Data usage may incur operator charges.
- Use WLAN. Disable Data Connection when not needed.

System Slowdown

1. Restart the phone.
2. Uninstall recent apps.
3. Factory reset (back up data first).

Freezing

Caused by open OS and conflicting apps. Avoid excessive installations. Restart periodically.

Battery Heating During Gaming

High CPU/RAM usage generates heat. Normal for all smartphones.

Improving Battery Life

- Disable unused WLAN, Bluetooth, GPS and sync.
- Lower screen brightness.
- Use power management tools.

App Installation Failures

- Incompatible version.
- Incomplete installation.
- App conflicts.

Accessing Background Apps

Press and hold the Home key.

Screen Off During Calls

- Saves power and prevents accidental touches.
- Proximity sensor dims screen near ear; lights when moved away. Press Power key if timed out.

IV. Main Function Guide

1. Home Screen

- Tap icons to open apps.
- Long-press and drag to reorder or remove shortcuts.

2. Adding Home Screen Widgets

- Long-press widget and drag to home screen.
- Remove same as shortcuts.

3. Contacts

- Import from SIM/SD, sync accounts or create new.

4. Making Calls

- Dial when network is available.
- Search contacts by name, pinyin or number.

5. Sending Messages

- Multiple recipients; send text, images, audio, video.

6. Text Input

- Use default or install third-party input methods.

7. Email

- Add account for sending/receiving with notifications.

8. Taking Photos/Videos

- Camera app with focus, effects and video mode.

9. Gallery

- Zoom, swipe, share and manage images.

10. Notification Panel

- Swipe down for notifications and quick toggles.

11. Music

- Play local music, sort by song/artist/album/playlist.

12. Multi-task Switching

- Long-press Home key to switch or close apps.

13. Browser

- Zoom webpages, use bookmarks.

14. Settings

- Customize device preferences.

V. Troubleshooting Common Faults

- **Enter PIN:** Enter valid PIN. Contact operator if unknown.
- **Enter PUK:** SIM locked. Contact operator.
- **Insert SIM:** Check SIM installation.
- **No Service:** Move to covered area.
- **Poor Call Quality:** Redial.
- **Short Standby Time:** Weak signal or aged battery.
- **Cannot Power On:** Charge battery.
- **Cannot Send SMS:** Check service settings.
- **Cannot Charge:** Check charger, environment or connection.
- **Cannot Add Contacts:** Memory full.
- **Unavailable Features:** Not enabled or unsupported.

VI. Important Statements

1. About the Phone

Manufacturer reserves the right to modify the product without notice and holds final interpretation rights.

2. Disclaimer

Manufacturer is not liable for issues from pre-installed or third-party software, content or services.

3. Limitation of Liability

To the fullest extent permitted by law, manufacturer and suppliers are not liable for any direct, indirect, special, incidental or consequential damages.

VII. More Information

For assistance with the two pre-installed apps, D-Chat App and D-Zone App, you can scan the QR code below to access the complete user manual.

